





Features

- 1. Flexible and cuttable every single LED
- 2. Good stability and reliability performance
- 3. Long lifespan with great lumen maintenance
- 4. Individually addressable LEDs allow you achieve dreaming color chasing effects like magic.
- 5. Multiple specifications for options

Application

andscape lighting, decorative lighting and cove lighting.

Installation

Fix by 3M self adhesive tape

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207





Optical & Electrical Parameters

Model No.	Light Color	Color Temperature/ Wavelength (mm)	Beam Angle	Luminous Flux (Im/m)	Ra	Efficacy (lm/w)	Voltage (DC V)	Power (W/m)
DN-N5050-30-5-RGB	R	615-630	120°	33	-	15	5	2.2
	G	515-530		79		36		2.2
	В	460-470		17		8		2.2
	R+G+B	100000		122		23		5.4
DN-N5050-60-5-RGB	R	615-630	120°	64	-	17	5	3.8
	G	515-530		150		41		3.8
	В	460-470		32		9		3.8
	R+G+B	100000		230		23		10.8

Other Parameters

Model No.	Quantity (pcs/m)	Standard Packing Length(mm)	Max Run (m)	Min Cuttable length(mm)	Working Temperature	Storage Temperature
DN-N5050-30-5-RGB	30	5000*10	4	33.3	-20~+60°C	-20~+70°C
DN-N5050-60-5-RGB	60	5000 10	2.5	16.7		

NOTE:

- Test environment temperature : 25±2°C.
- The above data is typical values. The actual data of each single product may differ from the typical values. The data is subject to change without notice.
- The above data are tested with sample of DN-N5050A. Different color temperature and IC will make luminous flux different.
- Single feed only. The max run length is related to the working current of the LED.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207





Profile Drawing

Unit mm

DN-N5050-30-5-RGB



DN-N5050-60-5-RGB



Length vs. Power vs. Voltage Drop

Model No.	Working Length (m)	Working Current (A)	Working Voltage (DC V)	Working Power (W)	Recommended Power Supply Configuration (W)	Power Supply Mode
DN-N5050-30-5-RGB	1	1.06		5.3	7	Single feed
	2	2.09		10.5	14	
	3	3.09	5	15.5	20	
	4	3.95		19.8	25	
	5	4.67		23.4	30	
DN-N5050-60-5-RGB	1	2.13		10.7	14	Single feed Run a cable back to the driver every
	2	4.13		20.7	26	
	2.5	5.26	5	26.3	33	
	3	5.72		28.6	36	
	4	6.11		30.6	39	
	5	6.21		31.1	40	5 meters

NOTE:

Test environment temperature : 25±2°C.

Run a cable back to the driver every 8 meters to achieve long series connection of DN-N5050A-30-5-RGB (within control point of controller). Run a cable back to the driver every 5 meters to achieve long series connection of DN-N5050A-60-5-RGB (within control point of controller). Supported controllers: controller with any of these IC (IC model no.: 16703P, 1903, 2811).

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207





Luminous Intensity Distribution Diagram



BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207





Average Beam Angle

	Flux Out: 183.3 lm		
1cm	164928,699764lx		3.7cm
2cm	41232,174941lx		7.39cm
3cm	18325,77752lx		11.09cm
4cm	10308,43735lx		14.78cm
5cm	6597,27991lx		18.48cm
6cm	4581,19438lx		22.18cm
7cm	3366,14281lx		25.87cm
8cm	2577,10934lx		29.57cm
9cm	2036,8639lx		33.26cm
10cm	1649,6998lx		36.96cm
Height	Eavg, Emax	Beam Angle: 113.71°	Diameter

Note:

The above data are tested when single light is normally on with color temperature 2700. Please ask the sales for other colors and specifications.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207



Blueview[®]

Packaging



1 Label the reel;





Put reel, accessory bag and desiccant together into static shielding bag;



6 Label the box;



Seal and label the static shielding bag;



Use packing belt to pack. Add edge protectors if necessary.



 Put the packed static shielding bag into carton box;

Packaging information

Model No.	Standard Packing Length(mm)	Carton Size (mm)	Meter/Reel	Reel/Carton	Net Weight(kg)	Gross Weight(kg)
DN-N5050-30-5-RGB	5000*10	550*400*340	5	100	16.85(1±10%)	18.15(1±10%)
DN-N5050-60-5-RGB	5000*10	550*400*340	5	100	16.85(1±10%)	18.15(1±10%)

Note:

• Five meters per reel, packed in the static shielding bag.

• The above quantity and weight are only for the illustrated packaging method. There will be differences in the

quantity and weight with other packaging methods.

Installation

1.Products and Tools





LED power supply



Self-tapping screw



Insulation Tape

BLUEVIEW ELEC-OPTIC TECH CO.,LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207

DIGITAL SERIES DN-N5050









Diagonal pliers



Electric drill

2.Installation Methods and Steps

By self adhesive tape



Peel away the self adhesive tape on the rear.

Install with clips



Clean the mounting surface



Finished

Attentions

- Before installation, check that the product parameters are consistent with the requirements (Seeing product specificationsor product labels)
- Load voltage, current, power and power supply should be matched with the product.
- Follow the instructions of wiring diagram (first connect the load and then the power supply) to avoid short circuit.
- Make sure the correct connection of positive and negative poles between led module and power supply. Otherwise, the light will not be on.
- Make sure the power cord firmly screwed into the terminal and it should not be pulled out by hands.
- The terminal should have insulation, waterproof and anti-corrosive treatment.
- If the working length exceeded the max run length, make sure to have extra power supply.
- If it needs higher current of a LED, make sure having extra cooling.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Fax: +86-28-8148 1258 Tel: +86-28-8148 0011 Mail: sales@blueviewled.com Web.: www.blueviewled.com Add: No.1000, Section 2, 2nd Konggang Road, Southwest Aviation Industrial Development Zone, Chengdu, Sichuan, China. Zip code: 610207



Stick the strips on the signage accordingly



Connect main line to power supply.



Connect the strips with compatible power supply



part based on the installation position.



Peel away the self adhesive tape on the rear.





Evenly arrange the strips with appropriate space in the light box.







Blueview®

Common Faults and Troubleshoot

Quick Guide						
Problems	Reasons	Solutions				
	No electric supply.	Fix the short circuit problem.				
All LEDs can not light on.	Automatic power protection from the open or short circuit in output of the power supply.	Fix the short circuit problem.				
	Wrong connection of power supply.					
LEDs can not light on partly.	Some switching mode power supplies are not powered.	Check the power supply system to fix it.				
	Power supply line error.					
	Mistaken wire connection of some of products	Correctly connection				
	Power overloaded.	Replace with more powerful power				
Brightness of LED is inconsistent tor insufficient.	Power supply circuit excessive consumption.	Make sure led module working voltage within ±5% of standard voltage, or keep balance by circuit power consumption.				
	Excessive quantities in series connection	Reduce the quantities in series connection to meet requirement.				
LED flicker.	Connection point fault.	Remove bad connection point.				
	Switching power supply failure.	Replace a new power supply.				
	Wrong Installation or use of products	Please follow the instructions				

Statements and Recycling

Statements:

Repair should be operated by a qualified technician, if the external circuit or main line of this product is damaged. The parameters given in this manual are typical values and for reference only. All illustrations and drawings in this manual are for reference. This product is subject to change without notice.

Recycling:

LED lighting products belongs to electronic products, please do recycling treatment according to the relevant WEEE directives.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207

🛕 Warning

- Do not disassemble or retrofit the light. Do not touch the surface of the light with a sharp object.
- Do not do live-line working during installation, especially for high voltage product.
- Do not use any organic chemical solvents.
- Use neutral glass adhesive to fix this product and it needs to be dried 4 hours in the open environment after operation.
- Treat the ends and the circuit connection points that are not connected to the main line with insulation,waterproof, and anti-corrosion in the installation.
- Use 20AWG (0.5mm2 or thicker core wire to avoid adverse consequences caused by overheating, if the power cable need to lengthen.
- Make sure the input voltage meets the requirements and lines are connected correctly before lighting on. This product is as backlight of signage, and do not use as general lighting. Series connection within the max run.
- The length of the power cable between the power supply and the led strip should not exceed 2 meters. Otherwise, large circuit loss will lead to inconsistent brightness
- Installation, maintenance and repair should be operated by a qualified technician.