





^{+86-28-8148 0011}

- +86-28-8148 1258
- sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone,Chengdu,Sichuan,China. ZIP:610207 Web.:www.blueviewled.com

80[0.39]



QG05-3





Note:for detail drawing,please consult sales rep.

Optical & Electrical Parameters

Model No.	CCT(K)	Beam Angle	Luminous Flux(Im/pcs)	Ra	Efficacy(Im/W)	Voltage (V DC)	Power (W/pcs)
	2800-3200		80		100	12	0.8
	3800-4000		80	- 80+ -	100		
QG05-2	4750-5300	180°	81		101		
QG05-2	6000-7000	100	81		101		
	7400-9400		81		101		
	9450-11250		81		101		
	2800-3200		130	80+	108	12	1.2
	3200-4200		130		108		
	4700-5300		132		110		
QG05-3	6000-7000	180°	132		110		
	7400-9400		132		110		
	9000-10000		132		110		
	10000-12000		132		110		

Other Parameters

Model No.	LED Qty/pc	Product Size L*W*H(mm)	Standard Run(pcs)	Max Run(pcs)	Working Temperature	Storage Temperature
QG05-2	2	38*16*9.8	90	90		00 · 70°0
QG05-3	3	60*16*9.8	75	75	-20~+60°C	-20~+70°C

NOTE:

1. Testing temperature: 25±2°C

2. The above data are typical values. The actual data of each single product may differ from the typical values. The data is subject to change without notice.

3. Different color temperature will make luminous flux different.

4. The "Quantity" above means the LED quantity of single module.

5. Luminous flux & power tolerance within $\pm 10\%$.

6. Max run is in single feed.

PAGE 2

+86-28-8148 0011

• +86-28-8148 1258

sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone,Chengdu,Sichuan,China. ZIP:610207 Web.:www.blueviewled.com



Luminous Intensity Distribution Diagram



AVERAGE BEAM ANGLE(50%): 178.8°

Average Illumination



Note:The above two figures are tested with the sample QG05-3 at 9000-10000K, for other data, please consult sales rep

PAGE 3

+86-28-8148 0011

+86-28-8148 1258

sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone,Chengdu,Sichuan,China. ZIP:610207 Web.:www.blueviewled.com



Reliability Test

Test Sort	Test item	Reference Standard	Test condition	Test result
	PTC test	Blueview	TH=-60°C/15M, TL= - 40°C /15m per times (temperature rise and fall for 45 minute)	
Environmental test	Room temperature aging test	Product Warranty	TH=80°C/4h, TH= - 40°C /4h continuous lightened up	PASS
	High temperature resistant test Policy		TH=80°C, continuous lightened up	
	Room temperature aging test		Ta=25°C, continuous lightened up	

packing



Prepare the desiccant and bind the product.



Seal the box.

Packaging information



Put neatly placed products into anti-static shielding bags



Seal the the carton and label accordingly.



Seal and label the static shielding bag.



Use packing belt to pack after adding the edge protectors.



Put the static shielding bag side by side into carton box.

Model No.	Product Size L*W*H(mm)	Carton Size(mm)	pcs/bag	bag/Carton	Net Weight(kg)	Gross Weight(kg)
QG05-2	38*16*9.8	380*380*345	90	20	16.70(1±10%)	17.50(1±10%)
QG05-3	60*16*9.8	390*390*325	75	20	18.70(1±10%)	19.70(1±10%)

Note:

The above quantity and weight are only for the illustrated packaging method. There will be differences in the quantity and weight with other packaging methods.

PAGE 4

+86-28-8148 0011

• +86-28-8148 1258

sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone,Chengdu,Sichuan,China. ZIP:610207 Web.:www.blueviewled.com



Installation

Connection Diagram



Installation Reference

Model No.	Surface Material	Depth(H)cm	Illumination(lux)	Evenness	Density (pcs/m²)	Spacing (X*Y)cm	Watt Density (W/m)	Visual Effects
		5	13300-15640	0.85	12*12	8*8	173	
		6	8220-9670	0.85	10*10	10*10	120	
		8	4830-5780	0.84	8*8	12*12	77	
QG05	White Soft Film	10	3640-4260	0.85	7*8	14*12	67	ОК
		12	3110-3480	0.89	7*8	14*12	67	
		15	2360-2590	0.91	7*8	14*12	67	
		18	1960-2120	0.92	7*8	14*12	67	



Note:

- 1. X indicates the horizontal center spacing between modules;
- 2. Y indicates the longitudinal center spacing between modules;
- 3. Single LED modules are arranged in a square, X=Y.
- 4. When the depth of light box H>18cm, use more products to satisfy Illumination demand
- 5. Please contact the sales for other data.
- 6. Customized wire length available.
- 7. The above data is for common demand , you can increase the density for actual demand.

Accessories & Tools



Diagonal Pliers



LED power supply



Connection Terminals



sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone, Chengdu, Sichuan, China. ZIP:610207 Web.:www.blueviewled.com

PAGE 5



Installation steps













1.Clean the mounting surface.

2.Peel away the release paper on the back of led modules and stick them onto mounting surface.

3. Evenly arrange the led modules with appropriate space.

4.Cut the modules according to the requirements and treat the cut place with insulation and waterproof arrangement.

Note: Cut in the middle of the wire.

5.If the product needs to be connected, it is better to fix with connection ends.

Note: Treat the thread with insulation,waterproof, and anti-corrosion arrangement as it cannot pull out by hands. 6.Make sure the correct connection of positive and negative poles between led module and power supply.

Note: Treat the thread with insulation,waterproof, and anti-corrosion arrangement as it cannot pull out by hands.

.....

+86-28-8148 0011+86-28-8148 1258

sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest





Attentions before installation

Before installation, check that the product parameters are consistent with the requirements (Seeing product specifications or product labels) Load voltage, current, power and power supply should be matched with the product.

Follow the instructions of wiring diagram (first connect the load and then the power supply) to avoid short circuit.

Make sure the correct connection of positive and negative poles between products and power supply. Otherwise, the light will not be on.

Make sure the power cord firmly screwed into the terminal and it should not be pulled out by hands.

The terminal should have insulation, waterproof and anti-corrosive treatment.

After installation, the fabric light box must be covered with cloth within 48 hours. Please avoid leaving the light box idle for a long time.

Common Faults and Troubleshoot

	Quick Gu	ide		
Problems	Reasons	Solutions		
	No electric supply.	Power on		
All LEDs can not light on.	Automatic power protection from the open or short circuit in output of the power supply.	Fix the short circuit problem.		
	Wrong connection of power supply.			
	Some switching mode power supplies are not powered.	Check the power supply		
LEDs can not light on partly.	Power supply line error.	system to fix it.		
	Mistaken wire connection of some of products	Correctly connection		
	Power overloaded.	Replace with more powerful power		
Brightness of LED is inconsistent tor insufficient	Power supply circuit excessive consumption.	Make sure the working voltage of the product within ±5% of standard voltage, or keep balance by circuit power consumption.		
tor insuncient.	Excessive quantities in series connection of the product	Reduce the quantities of the product i series connection to meet requirement		
	Connection point fault.	Remove bad connection point.		
LED flicker.	Switching power supply failure.	Replace a new power supply.		
	Wrong Installation or use of products	Please follow the instructions		

🛕 Warning

- Do not disassemble or retrofit the light. Do not touch the surface of the light with a sharp object.
- Do not do live-line working during installation, especially for high voltage product.
- Do not use any organic chemical solvents.
- Use neutral glass adhesive to fix this product and it needs to be dried 24 hours in the open environment after operation.
- Treat the ends and the circuit connection points that are not connected to the main line with insulation,waterproof, and anti-corrosion in the installation.
- Use 18AWG (0.75mm² cross-sectional area) or thicker core wire to avoid adverse consequences caused by overheating, if the power cable need to lengthen.
- Make sure the input voltage meets the requirements and lines are connected correctly before lighting on.
- This product is for signage, and do not use as general lighting.
- Series connection within the max run.
- The length of the power cable between the power supply and the led strip should not exceed 2 meters. Otherwise, large circuit loss will lead to inconsistent brightness.
- Installation, maintenance and repair should be operated by a qualified technician.

Statements and Recycling

Statements:

Repair should be operated by a qualified technician, if the external circuit or main line of this product is damaged. The parameters given in this manual are typical values and for reference only. All illustrations and drawings in this manual are for reference.

This product is subject to change without notice.

Recycling:

LED lighting products belongs to electronic products, please do recycling treatment according to the relevant WEEE directives.



+86-28-8148 0011

• +86-28-8148 1258

sales@blueviewled.com

Add:No.1000,Section 2,2nd Konggang Road, Southwest Aviation Industrial Development Zone,Chengdu,Sichuan,China. ZIP:610207 Web.:www.blueviewled.com