### CONSTANT CURRENT DRIVE SERIES CCN-H2835







## **Features**

- 1. High quality 2835 LED
- 2. Flexible and cuttable for different requirements
- 3. Good stability and reliability performance
- 4. Brightness and color temperature changes can be achieved via smart power supply

UU UU UU UU UU

- 5. Long lifespan with great lumen maintenance
- 6. Multiple specifications for options and customer settings available

## Application

landscape lighting, decorative lighting and cove lighting.

## Installation

#### Fix by 3M self adhesive tape

#### BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207



## **Optical & Electrical Parameters**

Model No.	Light Color	Color Temperature/ Wavelength(K/nm)	Beam Angle of Single Color	Luminous Flux (Im/m)	Ra	Efficacy (Im/w)	Voltage (DC V)	Power (W/m)
00011100054 400 00 14/01	WW	2700	120°	1600	80+	134	36-42	11.9
CCNH2835A-168-39-WN	CW	6500	120°	1700	80+	142	36-42	11.9
CCNH2835A-200-30-WN	WW	2700	120°	1700	80+	150	27-33	11.3
CCNH2033A-200-30-WIN	CW	6500	120°	1800	80+	160	27-33	11.3

## **Other Parameters**

Model No.	LED Quantity (pcs/m)	Product Size (mm)	Max Run (Single Feed) (m)	Min Cuttable length(mm)	Working Temperature	Storage Temperature
CCNH2835A-168-39-WN	168	5000*10	5	166.7	-25~+60°C	-25~+70°C
CCNH2835A-200-30-WN	200	5000*10	5	100	-25~+60°C	-25~+70°C

NOTE:


• Test environment temperature: 25±2°C.

• The above data is typical values. The actual data of each single product may differ from the typical values. The data is subject to change without notice.

## **Profile Drawing**

Unit:mm [inch]

#### CCNH2835A-168-39-WN




#### BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207





CCNH2835A-200-30-WN



Note: Please ask the sales for detail drawing

## Length vs. Power vs. Power Supply

Model No.	Working Length (m)	Working Current (A)	Working Voltage (D C V)	Working Power (W)	Recommended Power Supply Configuration(W)	Power Supply Mode
	1	0.3		12.6	15	Single Feed
	2	0.6	36-42	25.2	30	
CCNH2835A-168-39-WN	3	1.2		50.4	55	
	4	1.5		63	65	
	5	1.8		75.6	80	
CCNH2835A-200-30-WN	1	0.4	27-33	13.2	15	Single Feed
	2	0.8		26.4	30	
	3	1.2		39.6	45	
	4	1.6		52.8	55	
	5	2.0		66	70	


Note: Test environment temperature : 25±2°C.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207



Luminous Intensity Distribution Diagram





BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207

Specifications are subject to change without notice. Blueview™ 2018– All rights reserved. Made in China.

CONSTANT CURRENT DRIVE SERIES

**CCN-H2835** 





## Average Illumination

#### Flux Out: 1600 lm

1cm	164928,699764lx		3.7cm
2cm	41232,174941lx		7.39cm
3cm	18325,77752lx		11.09cm
4cm	10308,43735lx		14.78cm
5cm	6597,27991lx		18.48cm
6cm	4581,19438lx		22.18cm
7cm	3366,14281lx		25.87cm
8cm	2577,10934lx		29.57cm
9cm	2036,8639lx		33.26cm
10cm	1649,6998Ix		36.96cm
Height	Eavg, Emax	Beam Angle: 123.16°	Diameter

#### Note:

The above data are measurements of CCN-H2835A-168. Please ask the sales for other colors and specifications.

BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207


## CONSTANT CURRENT DRIVE SERIES CCN-H2835

## Blueview®


## Packaging




Label the reel;




Seal the carton box;




Put reel, accessory bag and desiccant together into static shielding bag;




Label the box;



Seal and label the static shielding bag;



Use packing belt to pack. Add edge protectors if necessary.



Put the packed static shielding bag into carton box;

#### Packaging information

Model No.	Product Size (mm)	Carton Size (mm)	Meter/Reel	Reel/Carton	Net Weight (kg)	Gross Weight (kg)
CCN-H2835A-168-39-WM	5000*10	550*400*340	5	100	16.85(1±10%)	18.15(1±10%)
CCN-H2835A-200-30-WN	5000*10	550*400*340	5	100	16.85(1±10%)	18.15(1±10%)

#### Note:

- Five meters per reel, packed in the static shielding bag
- The above quantity and weight are only for the illustrated packaging method. There will be differences in the quantity and weight with other packaging methods.

## Installation

#### **1.Products and Tools**



CCN-H2835







Clips

BLUEVIEW ELEC-OPTIC TECH CO.,LTD

Tel: +86-28-8148 0011 Fax: +86-28-8148 1258 Mail: sales@blueviewled.com Web.: www.blueviewled.com Add: No.1000, Section 2, 2nd Konggang Road, Southwest Aviation Industrial Development Zone, Chengdu,Sichuan, China. Zip code: 610207



Self-tapping screw





Electrical tape









#### 2.Installation Methods and Steps

#### By self adhesive tape



Peel away the self adhesive tape on the rear.

#### By clips




Clean the mounting surface.



Cut off the excess part based on the installation position.



Evenly arrange the strips with appropriate space in the light box.



Use soldering iron for welding if need connection.




Connect main line to power supply.



Connect the strips with compatible power supply.

# 

Peel away the self adhesive tape on the rear.



Evenly arrange the strips with appropriate space in the light box.



Stick the strips on the signage accordingly.

## Attentions

- Before installation, check that the product parameters are consistent with the requirements (Seeing product specificationsor product labels)
- Load voltage, current, power and power supply should be matched with the product.
- Follow the instructions of wiring diagram (first connect the load and then the power supply) to avoid short circuit.
- Make sure the correct connection of positive and negative poles between led module and power supply. Otherwise, the light will not be on.
- Make sure the power cord firmly screwed into the terminal and it should not be pulled out by hands.
- The terminal should have insulation, waterproof and anti-corrosive treatment.
- If the working length exceeded the max run length, make sure to have extra power supply.
- If it needs higher current of a LED, make sure having extra cooling.

#### BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu, Sichuan, China.Zip code: 610207

## CONSTANT CURRENT DRIVE SERIES CCN-H2835



## Common Faults and Troubleshoot

Quick Guide						
Problems	Reasons	Solutions				
	No electric supply.	Fix the short circuit problem.				
All LEDs can not light on.	Automatic power protection from the open or short circuit in output of the power supply.	Fix the short circuit problem.				
	Wrong connection of power supply.					
LEDs can not light on partly.	Some switching mode power supplies are not powered.	Check the power supply system to fix it.				
	Power supply line error.					
	Mistaken wire connection of some of products	Correctly connection				
Brightness of LED is inconsistent tor insufficient.	Power overloaded.	Replace with more powerful power				
	Power supply circuit excessive consumption.	Make sure led module working voltage within ±5% of standard voltage, or keep balance by circuit power consumption.				
	Excessive quantities in series connection of LED modules.	Reduce the quantities of LED modules in series connection to meet requirement.				
LED flicker.	Connection point fault.	Remove bad connection point.				
	Switching power supply failure.	Replace a new power supply.				
	Wrong Installation or use of products	Please follow the instructions				

## Statements and Recycling

#### Statements:

Repair should be operated by a qualified technician, if the external circuit or main line of this product is damaged. The parameters given in this manual are typical values and for reference only. All illustrations and drawings in this manual are for reference. This product is subject to change without notice.

#### Recycling:

LED lighting products belongs to electronic products, please do recycling treatment according to the relevant WEEE directives.

#### BLUEVIEW ELEC-OPTIC TECH CO., LTD

Tel: +86-28-8148 0011Fax: +86-28-8148 1258Mail: sales@blueviewled.comWeb.: www.blueviewled.comAdd: No.1000, Section 2, 2nd Konggang Road, SouthwestAviation Industrial Development Zone, Chengdu,Sichuan, China.Zip code: 610207

#### 🛕 Warning

- Do not disassemble or retrofit the light. Do not touch the surface of the light with a sharp object.
- Do not do live-line working during installation, especially for high voltage product.
- Do not use any organic chemical solvents.
- Use neutral glass adhesive to fix this product and it needs to be dried 4 hours in the open environment after operation.
- Treat the ends and the circuit connection points that are not connected to the main line with insulation,waterproof, and anti-corrosion in the installation.
- Use 18AWG (0.75mm2 or thicker core wire to avoid adverse consequences caused by overheating, if the power cable need to lengthen.
- Make sure the input voltage meets the requirements and lines are connected correctly before lighting on. This product is as backlight of signage, and do not use as general lighting. Series connection within the max run.
- The length of the power cable between the power supply and the led strip should not exceed 2 meters. Otherwise, large circuit loss will lead to inconsistent brightness.
- Installation, maintenance and repair should be operated by a qualified technician.